

# Sharples T-1600 Suspension Assembly

#	Description	Part Number
1	Balance Stand.....	8-48-30-2-I-01-B-OO
1a	Cap.....	8-48-30-2-I-1A-C-OO
1b	Screw.....	8-48-30-2-S-1B-C-OO
1c	Oil Cup.....	8-48-30-2-S-1C-A-OO
2	Balancing Rod.....	8-48-30-2-C-02-A-OO
3	Donut.....	8-48-30-2-C-03-A-OO
4	Washer.....	8-48-30-2-C-04-A-OO
5	Spring.....	8-48-30-2-C-05-A-OO
6	Spacer.....	8-48-30-2-C-06-A-OO
7a	Adjusting Washer.....	8-48-30-2-C-7A-A-OO
7b	Adjusting Washer.....	8-48-30-2-C-7B-A-OO
7c	Adjusting Washer.....	8-48-30-2-C-7C-A-OO
8	Felt Washer.....	8-48-30-2-S-08-A-OO
9	Key.....	8-48-30-2-C-09-A-OO
10	Washer.....	8-48-30-2-C-10-A-OO
11	Safety Block.....	8-48-30-2-W-11-C-OO
12	Hex Head Cap Screw.....	8-48-30-2-A-12-C-OO
13	Washer, Plain.....	8-48-30-2-C-13-C-OO



